




The Synchronization Experts.



# MANUAL

## TCR180PEX

**Time Code Reader and Generator**

April 23, 2024

Meinberg Funkuhren GmbH & Co. KG



# Table of Contents

<b>1</b>	<b>Copyright and Liability Exclusion</b>	<b>1</b>
<b>2</b>	<b>Imprint</b>	<b>2</b>
<b>3</b>	<b>Safety instructions for building-in equipment</b>	<b>3</b>
3.1	Important Safety Information and Safety Precautions . . . . .	3
3.2	Used Symbols . . . . .	4
3.3	Product Documentation . . . . .	5
3.4	Safety Hints TCR180PEX . . . . .	5
3.5	Prevention of ESD Damage . . . . .	6
3.6	Cabling . . . . .	7
3.7	Replacing the Lithium Battery . . . . .	7
<b>4</b>	<b>Important Product Information</b>	<b>8</b>
4.1	CE Marking . . . . .	8
4.2	UKCA Marking . . . . .	8
4.3	Maintenance and Modifications . . . . .	9
4.3.1	Replacing the Battery . . . . .	9
4.4	Disposal . . . . .	10
<b>5</b>	<b>TCR180PEX Features</b>	<b>11</b>
<b>6</b>	<b>Block Diagram TCR180</b>	<b>12</b>
<b>7</b>	<b>Master Oscillator</b>	<b>13</b>
<b>8</b>	<b>Functional Description of Receiver</b>	<b>14</b>
8.1	Input Signals . . . . .	18
8.2	Input Impedance for modulated Signals . . . . .	19
8.3	Photocoupler Input . . . . .	20
<b>9</b>	<b>Functionality of the Generator</b>	<b>21</b>
9.1	Time Code Outputs . . . . .	21
9.1.1	Modulated Outputs . . . . .	21
9.1.2	Unmodulated Outputs . . . . .	21
9.2	Pulse Outputs . . . . .	22
9.3	Asynchronous Serial Port . . . . .	23
9.4	Frequency Synthesizer . . . . .	23
9.5	Enabling of Outputs . . . . .	24
9.6	DCF77 Emulation . . . . .	24
9.7	Time Capture Inputs . . . . .	25
<b>10</b>	<b>Connectors and LEDs in the Bracket</b>	<b>26</b>
10.1	Pin Assignments of the 9pin D-SUB Connector . . . . .	27
10.2	D-SUB Pin Assignment of MultiRef Port . . . . .	28
<b>11</b>	<b>Putting into Operation</b>	<b>29</b>
11.1	Installing the TCR180PEX in Your Computer . . . . .	29
11.2	Power Supply . . . . .	29
11.3	Configuration of TCR180PEX . . . . .	29
<b>12</b>	<b>Firmware Update of the TCR180PEX.</b>	<b>30</b>

<b>13 Technical Specification TCR180PEX</b>	<b>31</b>
<b>14 Technical Appendix TCR180PEX</b>	<b>34</b>
14.1 Abstract of Time Code . . . . .	34
14.1.1 Description of IRIG-Codes . . . . .	34
14.2 Time code Format . . . . .	35
14.2.1 Time Code Format According to IRIG Standard . . . . .	35
14.2.2 Time Code Format According to AFNOR Standard . . . . .	36
14.3 Time Strings . . . . .	37
14.3.1 Meinberg Standard Time String . . . . .	37
14.3.2 Meinberg Capture String . . . . .	38
14.3.3 Uni Erlangen String (NTP) . . . . .	39
14.3.4 SAT Time String . . . . .	41
14.3.5 Computime Time String . . . . .	42
14.3.6 Format of the SPA Time String . . . . .	43
14.3.7 RACAL Standard Time String . . . . .	44
14.3.8 ION Time String . . . . .	45
14.4 PCI Express (PCIe) . . . . .	46
<b>15 RoHS Conformity</b>	<b>47</b>
<b>16 Declaration of Conformity for Operation in the European Union</b>	<b>48</b>
<b>17 Declaration of Conformity for Operation in the United Kingdom</b>	<b>50</b>

# 1 Copyright and Liability Exclusion

Except where otherwise stated, the contents of this document, including text and images of all types and translations thereof, are the intellectual property and copyright of Meinberg Funkuhren GmbH & Co. KG ("Meinberg" in the following) and are subject to German copyright law. All reproduction, dissemination, modification, or exploitation is prohibited unless express consent to this effect is provided in writing by Meinberg. The provisions of copyright law apply accordingly.

Any third-party content in this document has been included in accordance with the rights and with the consent of its copyright owners.

A non-exclusive license is granted to redistribute this document (for example, on a website offering free-of-charge access to an archive of product manuals), provided that the document is only distributed in its entirety, that it is not modified in any way, that no fee is demanded for access to it, and that this notice is left in its complete and unchanged form.

At the time of writing of this document, reasonable effort was made to carefully review links to third-party websites to ensure that they were compliant with the laws of the Federal Republic of Germany and relevant to the subject matter of the document. Meinberg accepts no liability for the content of websites not created or maintained by Meinberg, and does not warrant that the content of such external websites is suitable or correct for any given purpose.

While Meinberg makes every effort to ensure that this document is complete, suitable for purpose, and free of material errors or omissions, and periodically reviews its library of manuals to reflect developments and changing standards, Meinberg does not warrant that this specific document is up-to-date, comprehensive, or free of errors. Updated manuals are provided at [www.meinbergglobal.com](http://www.meinbergglobal.com) and [www.meinbergsupport.com](http://www.meinbergsupport.com).

You may also write to [techsupport@meinberg.de](mailto:techsupport@meinberg.de) to request an updated version at any time or provide feedback on errors or suggested improvements, which we are grateful to receive.

Meinberg reserves the right to make changes of any type to this document at any time as is necessary for the purpose of improving its products and services and ensuring compliance with applicable standards, laws & regulations.

## 2 Imprint

**Meinberg Funkuhren GmbH & Co. KG**  
Lange Wand 9, 31812 Bad Pyrmont, Germany

Phone: + 49 (0) 52 81 – 93 09 - 0  
Fax: + 49 (0) 52 81 – 93 09 - 230

Website: <https://www.meinbergglobal.com>  
Email: [info@meinberg.de](mailto:info@meinberg.de)

Date: April 23, 2024

## 3 Safety instructions for building-in equipment

### 3.1 Important Safety Information and Safety Precautions

The following safety information must be observed whenever the device is being installed or operated. Failure to observe this safety information and other special warnings or operating instructions in the product manuals constitutes improper usage and may violate safety standards and the manufacturer's requirements.



Depending on the configuration of your device or installed options, some information may not specifically apply to your device.



The device satisfies the requirements of the following EU regulations: EMC Directive, Low Voltage Directive, RoHS Directive and—where applicable—the Radio Equipment Directive.

If a procedure is marked with the following signal words, you may only proceed with it if you have understood and fulfilled all requirements. Hazard notices and other relevant information are classified and indicated as such in this manual according to the following system:



#### **DANGER!**

This signal word indicates a hazard with a high risk level . Such a notice refers to a procedure or other action that will very likely result in serious injury or even death if not observed or if improperly performed.



#### **WARNING!**

This signal indicates a hazard with a medium risk level . Such a notice refers to a procedure or other action that may result in serious injury or even death if not observed or if improperly performed.



#### **CAUTION!**

This signal word indicates a hazard with a low risk level . Such a notice refers to a procedure or other action that may result in minor injury if not observed or if improperly performed.















#### **ATTENTION!**

This signal word refers to a procedure or other action that may result in product damage or the loss of important data if not observed or if improperly performed.

## 3.2 Used Symbols

The following symbols and pictograms are used in this manual. Pictograms are used in particular to indicate potential hazards in all hazard categories.

Symbol	Beschreibung / Description
	IEC 60417-5031 Gleichstrom / <i>Direct current</i>
	IEC 60417-5032 Wechselstrom / <i>Alternating current</i>
	IEC 60417-5017 Erdungsanschluss / <i>Earth (ground) terminal</i>
	IEC 60417-5019 Schutzleiteranschluss / <i>Protective earth (ground) terminal</i>
	ISO 7000-0434A Vorsicht / <i>Caution</i>
	IEC 60417-6042 Vorsicht, Risiko eines elektrischen Schlages / <i>Caution, risk of electric shock</i>
	IEC 60417-5041 Vorsicht, heiße Oberfläche / <i>Caution, hot surface</i>
	IEC 60417-6056 Vorsicht, Gefährlich sich bewegende Teile / <i>Caution, moving parts</i>
	IEC 60417-6172 Trennen Sie alle Netzstecker / <i>Disconnect all power connectors</i>
	IEC 60417-5134 Elektrostatisch gefährdete Bauteile / <i>Electrostatic Discharge Sensitive Devices</i>
	IEC 60417-6222 Information generell / <i>General information</i>
	2012/19/EU Dieses Produkt fällt unter die B2B Kategorie. Zur Entsorgung muss es an den Hersteller übergeben werden. <i>This product is handled as a B2B-category product. To ensure that the product is disposed of in a WEEE-compliant fashion, it must be returned to the manufacturer.</i>



### 3.3 Product Documentation

Extensive documentation for the product is provided on the Meinberg Customer Portal – <https://www.meinberg.support>

The manuals can also be downloaded from the Meinberg website at <https://www.meinbergglobal.com/english/docs/>. On our website you can enter your system name into the search box at the top of the page to find the desired manual. If you have any questions or problems, our support team will be pleased to help you.



This manual contains important safety instructions for the installation and operation of the device. Please read this manual thoroughly before using the device.

This device may only be used for the purpose described in this manual. In particular, the specified operating limits of the device must be heeded. The person setting up the device is responsible for safety matters in relation to any larger system in which the device is installed!

Failure to observe these instructions may have an adverse impact on device safety!

Please keep this manual in a safe place.

This manual is only intended to be used by qualified electricians, or by persons who have been appropriately instructed by a qualified electrician and who are familiar with applicable national standards and with safety rules & regulations. This device may only be installed, set up, and operated by qualified personnel.

### 3.4 Safety Hints TCR180PEX

This building-in equipment has been designed and tested in accordance with the requirements of Standard DIN EN 62368-1 "Audio/video, information and communication technology equipment – Part 1: Safety requirements).

During installation of the building-in equipment in an end application (i.e. PC) additional requirements in accordance with Standard DIN EN 62368-1 have to be taken into account.

#### General Safety instructions

- The building-in equipment has been evaluated for use in office environment (pollution degree 2) and may be only used in this environment. For use in rooms with a higher pollution degree more stringent requirements are applicable.
- The equipment/building-in equipment was evaluated for use in a maximum ambient temperature of 50°C.
- Protection against fire must be assured in the end application.

### 3.5 Prevention of ESD Damage



#### ATTENTION!

An ESDS device (electrostatic discharge-sensitive device) is any device at risk of damage or malfunction due to electrostatic discharges (ESD) and thus requires special measures to prevent such damage or malfunction. Systems and modules with ESDS devices usually bear the following symbol:



#### Symbol Indicating Devices with ESDS Components

The following measures will help to protect ESDS components from damage and malfunction.

##### When preparing to dismantle or install devices:

Ground your body (for example, by touching a grounded object) before touching sensitive devices.

Ensure that you wear a grounding strap on your wrist when handling such devices. These straps must in turn be attached to an uncoated, non-conductive metal part of the system.

Use only tools and devices that are free of static electricity.

##### When transporting devices:

Devices must only be touched or held by the edges. Never touch any pins or conductors on the device.

##### When dismantling or installing devices:

Avoid coming into contact with persons who are not grounded. Such contact may compromise your connection with the earth conductor and thus also compromise the device's protection from any static charges you may be carrying.

##### When storing devices:

Always store devices in ESD-proof ("antistatic") bags. These bags must not be damaged in any way. ESD-proof bags that are crumpled or have holes cannot provide effective protection against electrostatic discharges.

ESD-proof bags must have a sufficient electrical resistance and must not be made of conductive metals if the device has a lithium battery fitted on it.

## 3.6 Cabling



### WARNING!

Danger of death from electric shock! Never work on cables while the power is live!  
Always disconnect the cables from the devices at **both** ends before working on the plugs and terminals of connected cables!

## 3.7 Replacing the Lithium Battery



### Skilled/Service-Personnel only: Replacing the Lithium Battery

The life time of the lithium battery on the receiver boards is at least 10 years. If the need arises to replace the battery, the following should be noted:

There is a Danger of explosion if the lithium battery is replaced incorrectly. Only identical batteries or batteries recommended by the manufacturer must be used for replacement.

The waste battery has to be disposed as proposed by the manufacturer of the battery.

## 4 Important Product Information

### 4.1 CE Marking

This product bears the CE mark as is required to introduce the product into the EU Single Market.



The use of this mark is a declaration that the product is compliant with all requirements of the EU directives effective and applicable as at the time of manufacture of the product.

These directives are listed in the EU Declaration of Conformity, appended to this manual as Chapter 16.

### 4.2 UKCA Marking

This product bears the British UKCA mark as is required to introduce the product into the United Kingdom (excluding Northern Ireland, where the CE marking remains valid).



The use of this mark is a declaration that the product is in conformity with all requirements of the UK statutory instruments applicable and effective as at the time of manufacture of the product.

These statutory instruments are listed in the UK Declaration of Conformity, appended to this manual as Chapter 17.

## 4.3 Maintenance and Modifications



### Important!

Before performing any maintenance work on or authorized modification to your Meinberg system, we recommend making a backup of any stored configuration data (e.g., to a USB flash drive using Meinberg Device Manager).

### 4.3.1 Replacing the Battery

Your device's clock module is fitted with a lithium battery (type CR2032) that is used to locally storage almanac data and sustain operation of the real-time clock (RTC) in the reference clock.

This battery has a life of at least ten years. However, if the device exhibits the following unexpected behaviors, the voltage of the battery may have dropped below 3 V, and the battery will need to be replaced:

- The reference clock has the wrong date or wrong time when the system is started.
- The reference clock repeatedly starts in Cold Boot mode (i.e., upon starting, the system has no ephemeris data saved whatsoever, resulting in the synchronization process taking a very long time due to the need to rediscover all of the visible satellites).
- Some configuration options relating to the reference clock are lost every time the system is restarted.

In this case, you should not replace the battery on your own. Please contact the Meinberg Technical Support team, who will provide you with precise guidance on how to perform the replacement.

## 4.4 Disposal

### Disposal of Packaging Materials



The packaging materials that we use are fully recyclable:

Material	Use for	Disposal
Polystyrene	Packaging frame/filling material	Recycling Depot
PE-LD (Low-density polyethylene)	Accessories packaging, bubble wrap	Recycling Depot
Cardboard	Shipping packaging, accessories	Paper Recycling

For information on the proper disposal of packaging materials in your specific country, please inquire with your local waste disposal company or authority.

### Disposal of the Device



This product falls under the labeling obligations of the Waste Electrical and Electronic Equipment Directive 2012/19/EU ("*WEEE Directive*") and thus bears this WEEE symbol. The presence of this symbol indicates that this electronic product may only be disposed of in accordance with the following provisions.



#### Important!

Do not dispose of the product or batteries via the household waste. Inquire with your local waste disposal company or authority on how to best dispose of the product or battery if necessary.

This product is considered to be a "B2B" product for the purposes of the WEEE Directive and is also classified as "IT and Telecommunications Equipment" in accordance with Annex I of the Directive.

It can be returned to Meinberg for disposal. Any transportation expenses for returning this product (at end-of-life) must be covered by the end user, while Meinberg will bear the costs for the waste disposal itself. If you wish for Meinberg to handle disposal for you, please get in touch with us. Otherwise, please use the return and collection systems provided within your country to ensure that your device is disposed of in a compliant fashion to protect the environment and conserve valuable resources.

### Disposal of Batteries

Please consult your local waste disposal regulations for information on the correct disposal of batteries as hazardous waste.

## 5 TCR180PEX Features

The board TCR180PEX has been designed as a "low profile" board for computers with PCI Express interface. Data transfer to the computer is done via a single PCI Express lane (x1 board). The TCR180PEX card decodes and generates modulated (AM) and unmodulated (DC Level Shift, DCLS) IRIG-A/B, AFNOR NF S87-500, IEEE C37.118, or IEEE 1344 time codes. AM codes are transmitted by modulating the amplitude of a sine wave carrier, unmodulated codes by variation of the width of pulses.

The TCR180PEX is equipped with a high quality oscillator which is disciplined as long as an input signal is available, and provides accurate time in holdover mode if the input signal is disconnected.

### Receiver:

Automatic gain control within the receive circuit for unmodulated codes allows decoding of IRIG-A/B, AFNOR NF S87-500, IEEE C37.118 or IEEE 1344 signals with a carrier amplitude of 600 mVpp to 8 Vpp. The input stage is electrically insulated and has an impedance of either 50  $\Omega$ , 600  $\Omega$  or 5 k $\Omega$ , selectable by a jumper. Modulated input signals can be supplied via BNC connector in the TCR180PEX's bracket.

Unmodulated (DC Level Shift, DCLS) time codes have to be supplied via the card's 9 pin D-Sub connector. The receive circuit is insulated by an onboard photocoupler which can be driven by TTL or RS-422 signals for example. When the card is shipped the contacts of the D-Sub connector are not wired to the photocoupler. Two DIP switches have to be set to the 'ON' position to make the inputs available via the connector.

### Generator:

The time code output of the TCR180PEX can generate time codes in IRIG-A/B, AFNOR NF S87-500, IEEE C37.118, or IEEE 1344 format. The output signal is available as modulated (3 Vpp / 1 Vpp into 50  $\Omega$ ) and unmodulated (DC Level Shift, DCLS) signal (TTL into 50  $\Omega$  and RS-422). A jumper on the board allows selection of active-high or active-low DCLS output.


Format and UTC offset of the incoming and outgoing time codes can be configured independently, so the TCR180PEX is well-suited for time code conversion.

Optionally the TCR180PEX can be delivered with optical inputs/outputs. The card provides two configurable serial interfaces (RS-232) COM. COM0 is available via the Sub-D connector, COM1 is accessible via an extra ribbon cable connector on the board. Three programmable pulse outputs are available via the D-Sub connector by setting appropriate DIP switches to the 'ON' position.

The extra ribbon cable connector on the board also provides two TTL inputs (CAP0 and CAP1) that can be used to time stamp external, asynchronous trigger slopes. The captured time stamps can be retrieved via the PCI-bus, or can be emitted as ASCII string via one of the serial interfaces.

TCR180PEX provides a synthesizer which can generate output frequencies from 1/8 Hz up to 10 MHz with TTL level into 50  $\Omega$  as a sine wave signal.

## 6 Block Diagram TCR180





## 7 Master Oscillator

By default the TCR180PEX is equipped with a TCXO (Temperature Compensated Xtal Oscillator) as master oscillator to provide a good time accuracy and frequency stability. As long as an input signal is supplied the frequency of the oscillator is adjusted from the input signal, and if the input signal is disconnected afterwards the card can still provide accurate time for a certain holdover interval. Optionally the card can be ordered with an OCXO (Oven Controlled Xtal Oscillator) which provides even better frequency stability, and thus provides more accuracy over a longer holdover interval than the TCXO.

All internal timing as well as the output signals are derived from the oscillator. The last known good oscillator adjustment value is stored in non-volatile memory, and is used as default after power-up.

The oscillator's 10 MHz output frequency is also available with TTL level via at a ribbon cable connector.

## 8 Functional Description of Receiver

After the received time code has passed a consistency check, the TCR180PEX's on-board software clock and battery buffered real time clock are synchronized according to the external time reference. If an error or inconsistency is detected in subsequent time code frames, or the input signal is disconnected, the on-board clock switches to holdover mode, where the time is derived from the on-board high quality oscillator which has been disciplined before.

All IRIG and similar time codes provide the time-of-day, and a day-of-year number (1...365/366). When converting the day-of-year number from the incoming time code to a calendar date then the result is ambiguous unless the year number is not known: the day after February 28 can be March 1, but can also be February 29 in case the year is a leap year.

Unfortunately, most of the commonly used IRIG code formats don't include a year number, in which case the year number used for the computation of the calendar date is retrieved from the battery buffered on-board real time clock.

So care must be taken that the on-board clock has been set to the correct date. The on-board date and time can be adjusted by sending a Meinberg Standard Time string to the serial interface COM0, or via the PCI bus by using the utility programs included in the driver software package.

If the configured time code format does provide a year number (e.g. IEEE 1344, IEEE C37.118, IRIG-Bxx6/Bxx7) then the year number from the time code is used instead of the year number from the on-board real time clock, and the on-board date is set accordingly.



Most of the commonly used IRIG code formats also don't provide an indicator whether the transported time is UTC, or local time with some offset from UTC. However, the TCR180PEX always needs to derive UTC time from the incoming time code since the card's on-board time is expected to run on UTC.

If no UTC offset is provided by the time code then a UTC offset parameter on the card first needs to be configured, depending on the time provided by the input signal. When the TCR180PEX is shipped then the UTC parameter is set to "unconfigured", and as long as this is the case the card does not synchronize to the input signal. So the UTC offset has to be configured first when the card is put into operation. The tools that come with the driver software package given an appropriate hint if this is the case.

Only if the used time code format provides the UTC offset (e.g. IEEE 1344, IEEE C37.118) the card uses the UTC offset from the time code, and thus even synchronizes to the input signal if the card's UTC parameter is still set to "unconfigured".

Care must be taken, however, if one of the IEEE 1344 or IEEE C37.118 codes is used: The main difference between these formats is the way the UTC offset is to be applied: subtracted or added. Unfortunately there are 3rd party IRIG devices out there which claim to use a IEEE 1344 code, but in fact handle the UTC offset as specified in IEEE C37.118. This may result in a wrong UTC time derived from the time code if local time is transported. A simple fix is usually to switch the card from one of the IEEE codes to the other one.

The TCR180PEX can automatically convert its on-board UTC time to some local time, including automatic

switching to and from DST year by year according to configurable rules. This is independent from the UTC offset of the incoming time code. The derived local time can be transmitted via the outgoing time code, the serial time strings, or can be read via the PCI interface.

The time zone is entered as offset of seconds from UTC, e.g. for Germany:  
**MEZ = UTC + 3600 sec, MESZ = UTC + 7200 sec**

The specific date of beginning and end of daylight saving can be generated automatically for several years. The receiver calculates the switching times using a simple scheme, e.g. for Germany:

**Beginning of daylight saving is the first sunday after March, 25th at two o'clock => MESZ**

**End of daylight saving is the first sunday after October, 25th at three o'clock => MEZ**

The parameters for time zone and switching to/from daylight saving can be set by using the included monitor program. If the same values for beginning and end of daylight saving are entered then no switching to DST is made.

The associated settings can be changed using the configuration software shipped with the driver packages.



Most IRIG codes don't include an announcement flag for the DST change, or for the insertion of a leap second, so the TCR180PEX will switch into free wheeling mode on such event, and resynchronize a few seconds later.

The board TCR180PEX decodes the following formats:

**Please note:** all "A" und "G" **Timecodes** are only available **after** warmed up phase of the oscillator!

A002:	1000pps, DC Level Shift pulse width coded, no carrier BCD time of year
A132:	1000pps, amplitude modulated sine wave signal, 10 kHz carrier frequency BCD time of year
A003:	1000pps, DC Level Shift pulse width coded, no carrier BCD time of year, SBS time of day
A133:	1000pps, amplitude modulated sine wave signal, 10 kHz carrier frequency BCD time of year, SBS time of day
B002:	100pps, DC Level Shift pulse width coded, no carrier BCD time of year
B122:	100pps, amplitude modulated sine wave signal, 1 kHz carrier frequency BCD time of year
B003:	100pps,DC Level Shift pulse width coded, no carrier BCD time of year, SBS time of day
B123:	100pps, amplitude modulated sine wave signal, 1 kHz carrier frequency BCD time of year, SBS time of day
B006:	100 pps, DC Level Shift, no carrier BCD time-of-year, Year
B126:	100 pps, AM sine wave signal, 1 kHz carrier frequency BCD time-of-year, Year
B007:	100 pps, DC Level Shift, no carrier BCD time-of-year, Year, SBS time-of-day
B127:	100 pps, AM sine wave signal, 1 kHz carrier frequency BCD time-of-year, Year, SBS time-of-day

AFNOR:	Code according to NF S-87500, 100 pps, wave signal, 1kHz carrier frequency, BCD time-of-year, complete date, SBS time-of-day, Signal level according to NF S-87500
IEEE 1344:	Code according to IEEE 1344-1995, 100 pps, AM sine wave signal, 1kHz carrier frequency, BCD time-of-year, SBS time-of-day, IEEE 1344 extensions for date, timezone, daylight saving and leap second in control functions (CF) segment. (also see table 'Assignment of CF segment in IEEE 1344 mode')
IEEE C37.118:	Like IEEE 1344 - with UTC offset to be applied reversely

## 8.1 Input Signals

The time code format has to be configured using the monitor software: if an amplitude-modulated signal (IRIG-A/B, AFNOR NF S-87500, IEEE C37.118 oder IEEE 1344) is configured then the input signal has to be supplied to the upper BNC connector in the TCR180PEX's bracket. A coaxial, shielded or twistet pair cable should be used.

A pulse width modulated (DC Level Shift, DCLS) signal has to be supplied via the 9-pin D-SUB connector. Two DIP switches have to be set to the "ON" position to wire the contacts of the D-Sub connector to the onboard photocoupler, and an appropriate DCLS time code format has to be configured using the monitor program.

Optionally an optical input can be equipped instead of the modulated input. It is available as ST-connector for GI 50/125  $\mu\text{m}$  or GI 62,5/125  $\mu\text{m}$  gradient fiber.



The board TCR180PEX can't be used to decode amplitude modulated and DC Level Shift signals simultaneously. Depending on the selected code format, only the signal at the BNC-connector or the D-Sub connector is decoded.

## 8.2 Input Impedance for modulated Signals

Except the AFNOR NF S87-500 standard there are no time code specifications for modulated signals which define the output impedance of a generator, or the input impedance of a receiver, so care must be taken that the specifications of this card meet the requirements of 3rd party devices.


The TCR180PEX provides a jumper to set the input impedance for modulated codes to 50  $\Omega$ , 600  $\Omega$ , or 5 k $\Omega$ .

Time code outputs provided by Meinberg devices provide a 50  $\Omega$  output impedance to match the transmission requirements with coaxial cable, so the receiver should be set to 50  $\Omega$  input impedance if only a single receiver is connected to a generator.

If T-connectors are used to provide several receivers with a single output signal from a generator then the resulting load impedance for the generator may be too low if all receivers have a low input impedance, so it's more appropriate to set the input impedance of all receivers to 600  $\Omega$ . This also meets the requirement of the AFNOR standard, so this is the default setting when the TCR180PEX is shipped.


Only if the external time code generator has a high output impedance (see specifications of the external time code generator) it may be required to set the input impedance to 5 k $\Omega$ .

The driver software shows a bar chart for evaluation of the signal level at the receiver input. The following detail of the TCR180PEX's placeplan shows the possible jumper settings and the associated input impedance:



### 8.3 Photocoupler Input

Pulse width modulated (DC Level Shift) codes are insulated by an onboard photocoupler. The connection scheme is shown below:



MultiRef-Port: Pin Assignment of the D-SUB 9 connector  
(see chapter [D-SUB Pin Assignment of MultiRef Port](#) )

The internal series resistance allows direct connection of input signals with a maximum high level of +12 V (TTL or RS-422 for example). If signals with a higher amplitude are used, an additional external series resistance has to be applied to not exceed the limit of the forward current of the input diode (60 mA). The forward current should not be limited to a value of less than 10 mA to ensure safe switching of the photocoupler.



## 9 Functionality of the Generator

The time code generator of TCR180PEX is based on a DDS (Direct Digital Synthesis) frequency generator which derives the sine carrier of the modulated code from the reference clock of the master oscillator. The modulation of carrier amplitude (modulated codes) or pulse duration (unmodulated, DC level shift codes) is synchronized to the generated pulse-per-second (PPS) signal derived from the software clock.



The generated time code is independent from the settings for the received code. Thus it's possible to generate a output signal with a different format and UTC offset than the input signal.

### 9.1 Time Code Outputs

TCR180PEX provides modulated and unmodulated (DC level shift) outputs. As an option, an optical output can be equipped instead of the modulated output. It is available as ST-connector for GI 50/125 $\mu$ m or GI 62,5/125 $\mu$ m gradient fiber.

#### 9.1.1 Modulated Outputs

The amplitude-modulated sine carrier is available a BNC-coaxial-plug connector in the bracket. The signal amplitude is 3Vpp (MARK) and 1Vpp (SPACE) into 50 Ohm. The encoding is made by the number of MARK-amplitudes during ten carrier waves. The following agreements are valid:

binary '0'	:	2 Mark - amplitudes, 8 SPACE-amplitudes
binary '1'	:	5 Mark - amplitudes, 5 SPACE-amplitudes
position-identifier	:	8 Mark - amplitudes, 2 SPACE-amplitudes

#### 9.1.2 Unmodulated Outputs

The pulse width modulated DC-signals are coexistent to the modulated output and are available with TTL level into 50 Ohm and as RS-422 signal. After bringing DIP-switches into the 'ON' position, these outputs are available at the D-Sub connector. The active state of the unmodulated outputs can be set up by a jumper on the board TCR180PEX

## 9.2 Pulse Outputs

The pulse generator of TCR180PEX provide three independent channels (PPO0, PPO1, PPO2). All of these TTL outputs can be mapped to pins at the 9-pin connector at the rear slot cover by using a DIP switch. Each output can be switched according to different, predefined conditions. The pulse length can be configured from 10 msec to 10 sec in steps of 10 msec. The output signal level can be inverted, if required.

By default when shipped the pulse outputs are only enabled after the receiver has synchronized after power-up. However, the settings can be changed so that outputs are always enabled immediately after power-up. The pulse outputs can be configured using the monitor program shipped with the driver software package. The following modes can be configured independently for each channel:

<b>Timer mode:</b>	Three "on" and "off" time pairs per day
<b>Cyclic mode:</b>	Periodically repeated pulses. A cycle time of two seconds would generate a pulse at 0:00:00, 0:00:02, 0:00:04 etc.
<b>DCF77-Simulation: mode:</b>	Outputs simulated DCF77-compatible time marks, representing the local time configured on the device.
<b>Single Shot Mode:</b>	A single pulse of programmable length is generated once a day at a programmable point of time.
<b>Per Sec. Per Min. Per Hr. modes:</b>	Pulses once per second, minute, or hour aligned with second boundary
<b>Synthesizer:</b>	Frequency output 1/8 Hz up to 10 MHz
<b>Time Codes:</b>	Generation of Time Codes as described in chapter "Time Codes"
<b>Idle-mode:</b>	The output is inactive

The default configuration for the pulse outputs is:

<b>PPO0:</b>	Pulse each second (PPS), active HIGH, pulse duration 200 msec
<b>PPO1:</b>	Pulse each minute (PPM), active HIGH, pulse duration 200 msec
<b>PPO2:</b>	DCF77 Simulation

## 9.3 Asynchronous Serial Port

The TCR180PEX has two serial interfaces COM0 (standard port) and COM1 (multi ref. port). At delivery the (COM0) is provided on the slot bracket. The interface (COM1) can optionally be used via a second D-SUB-9 connector.

By default, both interfaces remain inactive after the system is switched on, until the receiver is synchronized. By using the monitor program, however, the TCR180PEX can be configured so that the interfaces are activated immediately after switch-on.

Transmission speed, framing and mode of operation can be configured individually for each port. Both of the ports can be configured to transmit either time strings (once per second, once per minute, or on request with ASCII "?" only), or to transmit capture strings (automatically when available, or on request). The format of the output strings is ASCII, see the technical specifications at the end of this document for details.



**Please note:**

If a serial interface sends capture events automatically, they can't be read via PCI-bus, because they are deleted from the buffer memory after transmission.

## 9.4 Frequency Synthesizer

The frequency synthesizer can generate output frequencies of 1/8 Hz up to 10 MHz as sine wave signal and with TTL-level into 50 Ohm. If a frequency below 1 kHz has been selected the following decimal places lead to real fractions of Hertz:

0.1	1/8 Hz
0.3	1/3 Hz
0.6	2/3 Hz

The synthesizer is turned off if a frequency of 0 Hz is configured.

If the output frequency is below 10 kHz the phase of the output signal can be set from  $-360^\circ$  to  $+360^\circ$  with a resolution of  $0.1^\circ$ .

## 9.5 Enabling of Outputs

By default the time code output, the pulse outputs, the serial outputs, and the frequency synthesizer are disabled after power up until the receiver is synchronized. However, the monitor software can be used to configure each group of outputs so that they are always enabled immediately after power-up.




**Please note:** Enabling of the time code output and the programmable pulses are controlled by the same setting.

## 9.6 DCF77 Emulation

The time code receiver TCR180PEX generates TTL level time marks (active HIGH) which are compatible with the time marks broadcast by the German long wave transmitter DCF77. This long wave transmitter which is installed in Mainflingen near Frankfurt/Germany transmits the legal reference time of the Federal Republic of Germany: time of day, date of month and day of week in BCD coded second pulses. Once every minute the complete time information is transmitted. This time information always contains the announcement of daylight savings and leap seconds.

The coding scheme is given below:



M	Minutenmarke (0.1s)
R	Aussendung über Reserveantenne
A1	Ankündigung Beginn/Ende der Sommerzeit
Z1, Z2	Zonenzeitbits
	Z1, Z2 = 0, 1: Standardzeit (MEZ)
	Z1, Z2 = 1, 0: Sommerzeit (MESZ)
A2	Ankündigung einer Schaltsekunde
S	Startbit der codierten Zeitinformation
P1, P2, P3	gerade Paritätsbits


Time marks start at the beginning of new second. If a binary "0" is to be transmitted, the length of the corresponding time mark is 100 msec, if a binary "1" is transmitted, the time mark has a length of 200 msec. The information on the current date and time as well as some parity and status bits can be decoded from the time marks of the 15th up to the 58th second every minute. The absence of any time mark at the 59th second of a minute signals that a new minute will begin with the next time mark.

## 9.7 Time Capture Inputs

Capture 0 (CAP0) and Capture 1 (CAP1) of the standard port can be enabled by using the DIP switch for the D-SUB9 connector in the slot bracket. This allows any events to be recorded at any time. If a falling TTL edge is detected at one of these inputs, the microprocessor stores the number of the input and the current time in a buffer memory which can hold up to 500 entries. The capture events can be displayed using the monitor program or sent via the serial interface COM1.

The buffer memory can be used to record either a time-limited, fast sequence of events (interval down to 1.5 msec) or a continuous sequence of events with a lower repetition time (depending on the transmission rate of COM1). The output string consists of ASCII characters, a detailed description can be found in the back of this manual. If the buffer memory overflows, a message "\*\*\* capture buffer full" is output, if the time interval between two events at the same input is too short, the message "\*\*\* capture overrun" is displayed and sent.

## 10 Connectors and LEDs in the Bracket



The bracket of the board includes the BNC connector for the amplitude modulated time codes, four LEDs and a 9 pin D-Sub-plug.

Pressing the hidden key BSL is required for activating the Bootstrap-Loader before updating the firmware.

The 9 pin D-Sub-connector is wired to the board's serial port. Pin assignment can be seen from the figure below. This port can not be used as serial port for the computer. Instead, the clock uses the port to send out Meinberg's standard time string in order to control an external display or some other external device. The string is sent out once per second, once per minute or if requested by an incoming ASCII "?".


It is also possible to change the board time by sending such a string towards the clock. Transmission speed, framing and mode of operation can be modified using the monitor software. The string format is described in the section 'Technical Specifications' at the end of this manual.

### LED Indicators

- |    |   |  |
|----|---|--|
| 1. | blue:<br>off:<br>green:   | During the TCR180PEX initialization phase<br>Oscillator not warmed up<br>Oscillator warmed up  |
| 2. | green:<br>red:<br>yellow:<br>yellow/green (flashing):<br>yellow/red (flashing): | Correct time code detected<br>No correct time code detected<br>TCR180PEX synchronized by Multi.Ref. source<br>Holdover mode (Multi.Ref.), IRIG Code available<br>Holdover mode (Multi.Ref.), IRIG Code not available |
| 3. | green:<br>red:<br>yellow (flashing):  | Telegramm consistent<br>Telegramm inconsistent<br>Jitter to large  |
| 4. | red:<br>off:  | The internal timing of TCR180PEX is in holdover mode<br>The internal timing of TCR180PEX is synchronized to the received time code (Lock)  |

## 10.1 Pin Assignments of the 9pin D-SUB Connector


By default only the signals needed for the serial port COM0 are mapped to the pins of the connector. Whenever one of the additional signals is to be used the signal must be wired to a pin by putting the appropriate lever of a DIP switch to the ON position.




The table below shows the pin assignments for the standard D-SUB9 connector and the DIP switch lever assigned to each of the signals. Care must be taken when mapping a signal to **Pin 1, Pin 4, Pin 7 and Pin 9** of the connector, because one of two different signals can be mapped to these Pins. Only one of the associated DIP switches may be set to ON at the same time:

### Standard Port

9pin D-SUB	Signal	Signal Level	DIP-Switch ON	
1	VCC out	+5 V	<b>1</b>	<i>DIP 8 must be OFF</i>
1	PPO_0 (PPS) out	RS232	<b>8</b>	<i>DIP 1 must be OFF</i>
2	RxD 0 in	RS232	-	
3	TxD 0 out	RS232	-	
4	PPO_1 (PPM) out	TTL	<b>5</b>	<i>DIP 10 must be OFF</i>
4	10 MHz out	TTL	<b>10</b>	<i>DIP 5 must be OFF</i>
5	GND	-	-	
6	CAP 0 in	TTL	<b>2</b>	
7	CAP 1 in	TTL	<b>3</b>	<i>DIP 7 must be OFF</i>
7	/ DCLS out (B)	RS422	<b>7</b>	<i>DIP 3 must be OFF</i>
8	PPO_0 (PPS) out	TTL	<b>4</b>	
9	PPO_2 (DCF) out	TTL	<b>9</b>	<i>DIP 6 must be OFF</i>
9	DCLS out (A)	RS422	<b>6</b>	<i>DIP 9 must be OFF</i>



## 10.2 D-SUB Pin Assignment of MultiRef Port



### Connection of ribbon cable


To lead the "Multiref" signals through the SUB-D connector, the ribbon cable must be plugged to the appropriate boxed header:



The table below shows the pin assignment of the connector and the assignment of the individual switches in the "Multiref Port" block. Please note that **pin 1 and pin 4** of the connector can be assigned with two different signals. Only one switch at a time should be set to the ON position:

### Multi.Ref. Port

9pin D-SUB	Signal	Signal Level	DIP-Switch ON	
1	VCC out	+5 V	<b>1</b>	<i>DIP 7 must be OFF</i>
1	PPS in	TTL	<b>7</b>	<i>DIP 1 must be OFF</i>
2	RxD 1 in	RS232	-	
3	TxD 1 out	RS232	-	
4	PPO_1 (PPM) out	TTL	<b>5</b>	<i>DIP 10 must be OFF</i>
4	10 MHz out	TTL	<b>10</b>	<i>DIP 5 must be OFF</i>
5	GND	-	-	
6	+ DCLS in	photocoupler	<b>2</b>	
7	- DCLS in	photocoupler	<b>3</b>	
8	PPO_0 (PPS) out	TTL	<b>4</b>	
9	DCLS out	TTL into 50 Ohm	<b>9</b>	<i>DIP 6 must be OFF</i>





# 11 Putting into Operation

To achieve correct operation of the board, the following points must be observed.

## 11.1 Installing the TCR180PEX in Your Computer

Every PCI Express board is a plug & play board. After power-up, the computer's BIOS assigns resources like I/O ports and interrupt numbers to the board, the user does not need to take care of the assignments. The programs shipped with the board retrieve the settings from the BIOS.

The computer has to be turned off and its case must be opened. The radio clock can be installed in any PCI Express slot not used yet. The rear plane must be removed before the board can be plugged in carefully. The computer's case should be closed again and the time code signal can be connected to the coaxial plug at the clock's rear slot cover. After the computer has been restarted, the monitor software can be run in order to check the clock's configuration. The computer's case should be closed again and the time code signal must be connected to the appropriate connector.

After the board has been mounted and connected, the system is ready to operate. About 10 seconds after power-up the receiver's TCXO operates with the required accuracy.

## 11.2 Power Supply

All power supplies needed by TCR180PEX are delivered by the PCI-(Express) bus.

## 11.3 Configuration of TCR180PEX

The selection of the time code, configuration of the serial interface and a possible offset of the received time to UTC must be set up by the monitor software via the PCIExpress bus. In contrast to AFNOR NF S87-500 the IRIG telegram contains only the day of year (1...366) instead of a complete date. To ensure correct function of TCR180PEX, the date stored in the realtime clock of the board must be set when using IRIG codes therefore. This setting can be done by a terminal software also.



If the time zone of the received time code is not UTC, the local offset to UTC must be configured to ensure correct function of the driver software. If the local time zone is MEZ for example, the board must be set to a local offset of '+60min' (MEZ = UTC + 1 h).

The serial interface COM0 can be configured to send a time telegram with reference to UTC or to the received local time.

## 12 Firmware Update of the TCR180PEX.

On slot cards, with flash program memory, the firmware update is being performed using the Meinberg flash program "mbgflash" via the serial port COM0 of the slot card.

The update requires a specific firmware image that matches the slot card type. To install the "mbgflash" program download and execute the EXE file.

Download of mgbflash program:

<https://www.meinbergglobal.com/download/utls/windows/mbgflash-1.13.exe>

The update process can be performed as often as needed when faults occur, since it is independent from contents of the program memory. The current content of the program memory is kept until the update process sends the command to clear the program memory. In this case, the slot card is ready for operation after the computer is switched on again.

## 13 Technical Specification TCR180PEX

RECEIVER INPUT:	<p>AM-input (BNC-connector): insulated by a transformer impedance settable 50 <math>\Omega</math>, 600 <math>\Omega</math>, 5 k<math>\Omega</math> input signal: 600 mV<sub>pp</sub> to 8 V<sub>pp</sub> (Mark) other ranges on request</p> <p>DC Level Shift input (D-Sub-connector): insulated by photocoupler internal series resistance: 220 <math>\Omega</math> maximum forward current: 60 mA diode forward voltage: 1.0 V...1.3 V</p> <p>optional input(option): optical receive power: min. 3<math>\mu</math>W optical connector: ST-connector for GI 50/125<math>\mu</math>m or GI 62,5/125<math>\mu</math>m gradient fiber</p>
DECODING:	<p>decoding of the following telegrams possible: IRIG-A002 / A132 / A003 / A133 / A006 / A136 / A007 / A137 IRIG-B002 / B122 / B003 / B123 / B006 / B126 / B007 / B127 AFNOR NF S87-500 IEEE C37.118 IEEE 1344</p>
ACCURACY OF TIME BASE:	< 500 nsec compared to IRIG reference marker
REQUIRED ACCURACY OF TIME CODE SOURCE:	+/- 100ppm
HOLDOVER MODE:	<p>automatic switching to crystal time base accuracy approximately 1*10<sup>-8</sup> if decoder has been synchronous for more than 1h</p>
BACKUP-BATTERY:	<p>if the power supply fails, an onboard realtime clock keeps time and date information important system parameters are stored in the RAM of the system lifetime of the Lithium battery at least 10 years</p>
GENERATOR OUTPUTS:	<p>modulated output: unbalanced sine carrier, 1 kHz 3V<sub>pp</sub>(MARK), 1V<sub>pp</sub> (SPACE) into 50 <math>\Omega</math></p> <p>unmodulated outputs(DCLS): TTL into 50 <math>\Omega</math> RS-422 active high or low selectable by jumper</p> <p>optical output (option): optical power: typ. 15<math>\mu</math>W optical connector: ST-connector for GI 50/125<math>\mu</math>m</p>

	or GI 62,5/125 $\mu$ m gradient fiber	
PULSE OUTPUTS:	three programmable outputs, TTL level Default settings: active only 'if sync'	
	PPO_0:	change of seconds (PPS) pulse duration 200 msec valid on rising edge
	PPO_1:	change of minute (PPM) pulse duration 200 msec valid on rising edge
	PPO_2:	DCF simulation
ACCURACY OF PULSES:	better than $\pm 1 \mu$ sec after synchronization and 20 minutes of operation	
SERIAL PORT:	configurable RS-232 interface	
	baudrates:	300 Bd...115200 Bd
	framing:	7E2, 8N1, 8N2, 8E1
	7N2, 7E1, 801	
	mode of operation:	string per second string per minute string on request
	time telegram:	Meinberg Standard Uni Erlangen, SAT
	Meinberg Capture, ION Comptime, SPA, RACAL	
CAPTURE INPUTS:	triggered by falling TTL slope	
	pulse repetition time:	1.5 msec min.
	resolution:	800 nsec
	output of trigger event via PCI-bus or serial interface	
MASTER OSCILLATOR:	TCXO (Temperature Compensated Xtal Oscillator)	
	accuracy compared to IRIG-reference:	
	sync. and 20 min. of operation:	$\pm 5(10^{-9})$
	first 20 min. after sync.:	$\pm 1(10^{-8})$
	accuracy of oscillator:	
	holdover, 1 day:	$\pm 1(10^{-7})$
	holdover, 1 year:	$\pm 1(10^{-6})$
	short term stability:	
	$\leq 10$ sec, synchronized:	$\pm 2(10^{-9})$
	$\leq 10$ sec, holdover:	$\pm 5(10^{-9})$
	temperature dependant drift:	
	holdover:	$\pm 1(10^{-6})$
	phase noise:	
	1 Hz besides carrier:	-60 dB/Hz
	10 Hz besides carrier:	-90 dB/Hz
	100 Hz besides carrier:	-120 dB/Hz
	1 kHz besides carrier:	-130 dB/Hz
FREQUENCYSYNTHESIZER:	output frequency:	1/8 Hz up to 10MHz

	accuracy:	like system accuracy
	1/8 Hz to 10 kHz: pulse per second	Phase synchronous to
	10 kHz to 10 MHz: < 0.0047 Hz	deviation of frequency
	outputs: sine wave 1.5Vrms output impedance 200 $\Omega$	TTL into 50 $\Omega$
RELIABILITY OF OPERATION:	microprocessor supervisory circuit provides watchdog timer, power supply monitoring and backup battery switchover software watchdog monitors correct program flow and generates a reset in case of error detection	
INITIALIZATION:	software and realtime clock can be set by a serial Meinberg Standard Telegram via COM0 or the PCI-Express bus	
BUS-INTERFACE:	Single lane (x1) PCI Express (PCIe) Interface compatible to PCI Express specification r1.0a	
DATA FORMAT:	binary, byte serial	
OUTPUTS:	pulse per second (PPS): TTL- and RS-232 level positive pulse, pulse duration 200 msec pulse per minute (PPM): TTL level positive pulse, pulse duration 200 msec	
POWER REQUIREMENT:	+3.3 V: $\approx$ 250 mA +12 V : $\approx$ 90 mA  power supplies provided by PCI Express interface	
Board DIMENSION:	"low profile" slot card (69 mm x 150 mm)	
AMBIENT TEMPERATURE:	0 ... 50°C	
HUMIDITY:	max. 85 %	


# 14 Technical Appendix TCR180PEX

## 14.1 Abstract of Time Code

The transmission of coded timing signals began to take on widespread importance in the early 1950's. Especially the US missile and space programs were the forces behind the development of these time codes, which were used for the correlation of data. The definition of time code formats was completely arbitrary and left to the individual ideas of each design engineer. Hundreds of different time codes were formed, some of which were standardized by the "Inter Range Instrumentation Group" (IRIG) in the early 60's.


The TCR180PEX supports decoding and generating of IRIG-A, IRIG-B, AFNOR NF S87-500, IEEE C37.118 and IEEE 1344.

### 14.1.1 Description of IRIG-Codes



14.2 Time code Format

14.2.1 Time Code Format According to IRIG Standard



## 14.2.2 Time Code Format According to AFNOR Standard





## 14.3 Time Strings

### 14.3.1 Meinberg Standard Time String

The Meinberg Standard Time String is a sequence of 32 ASCII characters starting with the <STX> (Start-of-Text) character and ending with the <ETX> (End-of-Text) character. The format is as follows:

`<STX>D:dd.mm.yy;T:w;U:hh.mm.ss;uvxy<ETX>`

The letters printed in italics are replaced by ASCII-formatted numbers, whereas the other characters are directly part of the time string. The groups of characters as defined below:

<STX>	Start-of-Text, ASCII code 02h sent with one-bit accuracy at the change of each second		
dd.mm.yy	The date:		
dd	Day of Month	(01–31)	
mm	Month	(01–12)	
yy	Year of the Century	(00–99)	
w	The day of the week		(1–7, 1 = Monday)
hh.mm.ss	The time:		
hh	Hours	(00–23)	
mm	Minutes	(00–59)	
ss	Seconds	(00–59, or 60 during leap second)	
uv	Clock status characters (depending on clock type):		
u:	'#'	GPS: Clock is in free-run mode (no exact synchronization)	
		PZF: Time frame not synchronized	
		DCF77: Clock has not synchronized since last reset	
	' '	(space, 20h)	
		GPS: Clock is synchronized (base accuracy is reached)	
		PZF: Time frame is synchronized	
		DCF77: Clock has synchronized since last reset	
v:	'*'	GPS: Receiver has not checked its position	
		PZF/DCF77: Clock currently running off XTAL	
	' '	(space, 20h)	
		GPS: Receiver has determined its position	
		PZF/DCF77: Clock is synchronized with transmitter	
x	Time zone indicator:		
	'U'	UTC	Universal Time Coordinated, formerly GMT
	' '	CET	European Standard Time, daylight saving disabled
	'S'	(CEST)	European Summertime, daylight saving enabled
y	Announcement of clock jump during last hour before jump enters effect:		
	'!'	Announcement of start or end of Daylight Saving Time	
	'A'	Announcement of leap second insertion	
	' '	(Space, 20h) nothing announced	
<ETX>	End-of-Text, ASCII code 03h		

### 14.3.2 Meinberg Capture String

The Meinberg Capture String is a sequence of 31 ASCII characters terminated by a <CR><LF> (Carriage Return/Line Feed) sequence. The format is as follows:

*CHx<SP>dd.mm.yy\_hh:mm:ss.fffffff<CR><LF>*

The letters printed in italics are replaced by ASCII-formatted numbers, whereas the other characters are directly part of the time string. The groups of characters as defined below:

x	0 or 1 corresponding on the number of the capture input		
<SP>	Space, ASCII code 20h		
dd.mm.yy	Capture date:		
	dd	Day of Month	(01–31)
	mm	Month	(01–12)
	yy	Year of the Century	(00–99)
hh:mm:ss.fffffff	Capture time:		
	hh	Hours	(00–23)
	mm	Minutes	(00–59)
	ss	Seconds	(00–59, or 60 during leap second)
	fffffff	Fractions of second, 7 digits	
<CR>	Carriage Return, ASCII code 0Dh		
<LF>	Line Feed, ASCII code 0Ah		

### 14.3.3 Uni Erlangen String (NTP)

The Uni Erlangen String (NTP) of a GPS clock is a sequence of 66 ASCII characters starting with the <STX> (start-of-text) character and ending with the <ETX> (end-of-text) character. The format is as follows:

```
<STX>dd.mm.yy; w; hh:mm:ss; voo:oo; acdfg i;bbb.bbbbn lll.lllle hhhhm<ETX>
```

The letters printed in italics are replaced by ASCII-formatted numbers, whereas the other characters are directly part of the time string. The groups of characters are as defined below:

<STX>	Start-of-Text, ASCII code 02h sent with one-bit accuracy at the change of each second		
dd.mm.yy	The date: <i>dd</i> Day of Month (01–31) <i>mm</i> Month (01–12) <i>yy</i> Year of Century (00–99)		
w	Day of the week (1–7, 1 = Monday)		
hh.mm.ss	The time: <i>hh</i> Hours (00–23) <i>mm</i> Minutes (00–59) <i>ss</i> Seconds (00–59, or 60 during leap second)		
v	-/+ sign of the offset of local timezone relative to UTC		
oo:oo	Offset of local time zone relative to UTC in hours and minutes		
ac	Clock status characters: a: '#' Clock has not synchronized since reset '' (Space, 20h) Clock has synchronized since reset  c: '*' GPS receiver has not checked its position '' (Space, 20h) GPS receiver has determined its position		
d	Time zone indicator: 'S' CEST European Summertime, Daylight Saving Time enabled '' CET European Standard Time, Daylight Saving Time disabled		
f	Announcement of clock jump during last hour before jump enters effect: '!' Announcement of start or end of Daylight Saving Time '' (Space, 20h) nothing announced		
g	Announcement of clock jump during last hour before jump enters effect: 'A' Announcement of leap second insertion '' (Space, 20h) nothing announced		
i	Leap second insertion 'L' Leap second is currently to be inserted (only active in 60th second) '' (Space, 20h) No leap second to be inserted		
bbb.bbbb	Geographical latitude of receiver position in degrees Leading characters padded by Space characters (20h)		

n	<p>Latitudinal hemisphere, with the following characters possible:</p> <p>‘N’      North of Equator</p> <p>‘S’      South of Equator</p>
111.1111	<p>Geographical longitude of receiver position in degrees</p> <p>Leading characters padded by Space characters (20h)</p>
e	<p>Longitudinal hemisphere, with the following characters possible:</p> <p>‘E’      East of Greenwich Meridian</p> <p>‘W’      West of Greenwich Meridian</p>
hhhh	<p>Altitude above WGS84 ellipsoid in meters</p> <p>Leading characters padded by Space characters (20h)</p>
<ETX>	End-of-Text, ASCII code 03h



### 14.3.5 Computime Time String

The Computime time string is a sequence of 24 ASCII characters, starting with the character `T` and terminated with the character `<LF>` (Line Feed, ASCII code 0Ah). The format is as follows:

`T:yy:mm:dd:ww:hh:mm:ss<CR><LF>`

The letters printed in italics are replaced by ASCII numbers whereas the other characters are unalterable parts of the time string. The groups of characters as defined below:

T	Start character
	Sent with 1-bit accuracy at the start of the second.
yy:mm:dd	The current date:
yy	Year without century (00–99)
mm	Month (01–12)
dd	Day of the month (01–31)
ww	Day of the week (1–7, 1 = Monday)
hh:mm:ss	The current time:
hh	Hours (00–23)
mm	Minutes (00–59)
ss	Seconds (00–59, or 60 during leap second)
<CR>	Carriage Return (ASCII code 0Dh)
<LF>	Line Feed (ASCII code 0Ah)

14.3.6 Format of the SPA Time String

The ABB SPA Time String is a sequence of 32 ASCII characters starting with the characters ">900WD" and ending with the <CR> (Carriage Return) character. The format is:

>900WD:*jj-mm-tt\_hh.mm;ss.fff*:cc<CR>

The letters printed in italics are replaced by ASCII numbers whereas the other characters are part of the time string. The groups of characters as defined below:

jj-mm-tt	the current date:		
jj	year of the century	(00..99)	
mm	month	(01..12)	
tt	day of month	(01..31)	
–	Space	(ASCII-code 20h)	
hh.mm;ss.fff	the current time:		
hh	hours	(00..23)	
mm	minutes	(00..59)	
ss	seconds	(00..59, or 60 while leap second)	
fff	milliseconds	(000..999)	
cc	Checksum. EXCLUSIVE-OR result of the previous characters, displayed as a HEX byte (2 ASCII characters 0..9 or A..F)		
<CR>	Carriage Return	ASCII Code 0Dh	

### 14.3.7 RACAL Standard Time String

The RACAL Standard Time String is a sequence of 16 ASCII characters started by a X character and terminated by the <CR> (Carriage Return, ASCII code 0Dh) character. The format is as follows:

*XGUyymmddhhmmss*<CR>

The letters printed in italics are replaced by ASCII-formatted numbers, whereas the other characters are directly part of the time string. The groups of characters are as defined below:

X	Start character, ASCII code 58h Sent with one-bit accuracy at the change of each second		
G	Control character, ASCII code 47h		
U	Control character, ASCII code 55h		
yymmdd	Current date:		
yy	Year of Century	(00–99)	
mm	Month	(01–12)	
dd	Day of Month	(01–31)	
hh:mm:ss	Current time:		
hh	Hours	(00–23)	
mm	Minutes	(00–59)	
ss	Seconds	(00–59, or 60 during leap second)	
<CR>	Carriage Return, ASCII code 0Dh		



14.3.8 ION Time String

The ION time string is a sequence of 16 ASCII characters starting with the <SOH> (Start of Header, ASCII code 01h) ASCII control character and ending with the <LF> (Line Feed, ASCII code 0Ah) character. The format is as follows:

<SOH>*ddd:hh:mm:ssq*<CR><LF>


The letters printed in italics are replaced by ASCII-formatted numbers, whereas the other characters are directly part of the time string. The groups of characters as defined below:

<SOH>	Start of Header (ASCII code 01h) sent with one-bit accuracy at the change of each second		
ddd	Day of Year	(001–366)	
hh:mm:ss	Current time:		
hh	Hours	(00–23)	
mm	Minutes	(00–59)	
ss	Seconds	(00–59, or 60 while leap second)	
q	Quality Indicator	Space (ASCII code 20h) "?" (ASCII code 3Fh)	Time Sync (GPS Lock) No Time Sync (GPS Fail)
<CR>	Carriage Return (ASCII code 0Dh)		
<LF>	Line Feed (ASCII code 0Ah)		


## 14.4 PCI Express (PCIe)

The main technical innovation of PCI Express is a serial data transmission compared to the parallel interfaces of other computer bus systems like ISA, PCI and PCI-X.

PCI Express defines a serial point-to-point connection, the so-called Link:



The data transfer within a Link is done via Lanes, representing one wire pair for sending and one wire pair for receiving data:



This design leads to a full duplex connection clocked with 2.5 GHz capable of transferring a data volume of 250 MB/s per lane in each direction. Higher bandwidth is implemented by using multiple lanes simultaneously. A PCI Express x16 slot for example uses sixteen lanes providing a data volume of 4 GB/s. For comparison: when using conventional PCI the maximum data transfer rate is 133 MB/s, PCI-X allows 1 GB/s but only in one direction respectively.

## 15 RoHS Conformity

### Conformity with EU Directive 2011/65/EU (RoHS)

We hereby declare that this product is compliant with the European Union Directive 2011/65/EU and its delegated directive 2015/863/EU "Restrictions of Hazardous Substances in Electrical and Electronic Equipment" and that no impermissible substances are present in our products pursuant to these Directives.

We warrant that our electrical and electronic products sold in the EU do not contain lead, cadmium, mercury, hexavalent chromium, polybrominated biphenyls (PBBs), polybrominated diphenyl ethers (PBDEs), bis(2-ethylhexyl)phthalat (DEHP), benzyl butyl phthalate (BBP), dibutyl phthalate (DBP), or diisobutyl phthalate (DIBP) above the legal limits.



# 16 Declaration of Conformity for Operation in the European Union

## EU-Konformitätserklärung

Doc ID: TCR180PEX-April 23, 2024

**Hersteller** Meinberg Funkuhren GmbH & Co. KG  
*Manufacturer* Lange Wand 9, D-31812 Bad Pyrmont

erklärt in alleiniger Verantwortung, dass das Produkt,  
*declares under its sole responsibility, that the product*

**Produktbezeichnung** TCR180PEX  
*Product Designation*

auf das sich diese Erklärung bezieht, mit den folgenden Normen und Richtlinien übereinstimmt:  
*to which this declaration relates is in conformity with the following standards and provisions of the directives:*

EMV – Richtlinie <i>EMC Directive</i>	EN 61000-6-2:2019 EN IEC 61000-6-3:2021 EN 55035:2017/A11:2020 EN 55032:2015 + AC:2016 + A11:2020 + A1:2020
2014/30/EU	

Niederspannungsrichtlinie <i>Low-voltage Directive</i>	EN IEC 62368-1:2020 + A11:2020
2014/35/EU	

RoHS – Richtlinie <i>RoHS Directive</i>	EN IEC 63000:2018
2011/65/EU + 2015/863/EU	

## EU-Declaration of Conformity

Doc ID: TCR180PEX-April 23, 2024

Diese EU-Konformitätserklärung umfasst alle nachfolgend aufgeführten Gerätekonfigurationen:  
*This UKCA Declaration of Conformity further covers all the device configurations listed below:*

Bad Pyrmont, den April 23, 2024

Aron Meinberg  
Quality Management



# 17 Declaration of Conformity for Operation in the United Kingdom

UKCA Declaration of Conformity  
 Doc ID: TCR180PEX-April 23, 2024

Manufacturer

Meinberg Funkuhren GmbH & Co. KG  
 Lange Wand 9  
 31812 Bad Pyrmont  
 Germany

*declares that the product*

Product Designation

TCR180PEX

*to which this declaration relates, is in conformity with the following standards and provisions of the following regulations under British law:*

Electromagnetic Compatibility Regulations 2016 (as amended) <i>SI 2016/1091</i>	EN IEC 61000-6-2:2019 EN IEC 61000-6-3:2021 EN 55035:2017/A11:2020 EN 55032:2015 + AC:2016 + A11:2020 + A1:2020
Electrical Equipment (Safety) Regulations 2016 (as amended) <i>SI 2016/1101</i>	EN IEC 62368-1:2020/A11:2020
The Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations 2012 (as amended) <i>SI 2012/3032</i>	EN IEC 63000:2018

## UKCA Declaration of Conformity

Doc ID: TCR180PEX-April 23, 2024

*This UKCA Declaration of Conformity further covers all the device configurations listed below:*

Bad Pyrmont, Germany, dated April 23, 2024

---

Aron Meinberg  
Quality Management

